


Fit D.L.D., D.L.R., and D.L.T. stem instruction sheet


1. The D.L.D. (Down Low Drop) stem was designed to drop your bars as low as possible but will damage your frame's top-tube if it does not clear when turned 180 degrees. Please use spacers to raise stem if necessary to clear your frame's top-tube when bars are turned 180 degrees.



2. The D.L.T., D.L.R. and D.L.D. stems all use our own "Flat-top" clamping system for ease of installation and a clean look.

Step 1) With the handlebar installed tighten the top (front on D.L.T.) two handlebar clamp bolts until they are snug. There should be no gap between the stem cap and body at the top at this point.

Step 2) Tighten the lower (back on D.L.T.) two handlebar clamp bolts to secure the handlebar.



Please use the supplied 6mm Allen wrench only; no other leverage is necessary and using too much may damage your bolts and/or stem.

Keep it on the Down Low

